


DIMENSIONS

NOTE: Dimensions are measured at the intersection of projected adjacent planes.



THREE - PHASE TRANSFORMER BOX PAD DIMENSIONS CHART (Inches)

| PAD-VAULT CAT. NO. | TOP SURFACE A X B | TOP OPENING C X D | E | F | G | H | J | K | L | UNITS/ PALLET |
|-----------------------|-------------------------|-------------------------|------|----|---|----|---|---|-----|------------------|
| BP3500 | 52 X 52.5 | 42 X 15.5 | 65 | 64 | 4 | 31 | 2 | 5 | 5 | 7 |
| BP3500A | 70 X 52.5 | 60 X 15.5 | 65 | 82 | 4 | 31 | 2 | 5 | 5 | 7 |
| BP5500 | 62 X 55 | 52 X 15.5 | 67.5 | 74 | 4 | 31 | 2 | 5 | 5 | 6 |
| BP7000 | 72 X 72 | 48 X 18 | 84 | 84 | 4 | 32 | 2 | 6 | 12 | 6 |
| BP7000-15 | 72 X 72 | 48 X 18 | 82 | 82 | 4 | 15 | 2 | 6 | 12 | 8 |
| BP7000A-18 | 75 X 63 | 60 X 18 | 73 | 85 | 4 | 18 | 2 | 6 | 7.5 | 7 |

Rev 12/02